

## OTHER PRODUCTS IN OUR RANGE

### HYDRAULIC GRAIN AUGER



**DIAMETER:** 325, MM.  
**LENGTH:** 5,00, 6,00, M.  
**UNIONS:** BOLTED OR SLEEVE.  
**ACCESSORIES:** WIDE VARIETY (INLETS, OUTLETS, EXTENSIONS, ETC.) WHICH ALLOWS PRODUCT CUSTOMISATION.  
**POSSIBILITY OF:** HOPPER (WIDTH: 0.60, 1.00, 1.60 METRES) AND TRAILER.

### CONVEYOR BELT (HYDRAULIC AND ELECTRIC)



**LENGTH:** 3, 4, 5, 6, 7, 8 AND 9 M.  
**BUCKET TYPE:** HANDLING OF DELICATE SEEDS AND NUTS.  
**RATCHET OR OMEGA TYPE:** HANDLING OF FRUIT.  
**AGRI-FOOD INDUSTRY:** SMOOTH OR MODULAR (ALLOWS WASHING).

### INTER-ROW CULTIVATOR



**MACHINE FOR THE ELIMINATION OF WEEDS BETWEEN ROWS.**  
ALLOWS THE USE OF HOE BLADES AND ACCESSORIES OF ANY NATURE IN ORDER TO WORK THE LAND TO PERFECTION. WITH PLATES TO PROTECT CROPS WHEN THEIR CONDITION SO REQUIRES.  
MODULAR CHASSIS ALLOWING USE WITH CROPS OF ANY NATURE INDEPENDENTLY OF THE SEPARATION BETWEEN ROWS (FROM 15 TO 80 CM).  
RIGID OR HYDRAULICALLY FOLDING CHASSIS.

# LeciTech

FARMING EQUIPMENT

## FRONT HOPPER PRESSURISED FOR SEED AND FERTILISERS

MODEL: *FERTIMAX 2300*

2300  
LITRE

**HOPPER DIMENSIONS  
FERTIMAX 2300:**  
225 X 155 X 160 CM



### VERSIONS :

**LS**  
TRANSFER OF FERTILISERS  
AND SEEDS TO A SEEDER

**BI**  
DOSING OF ONE PRODUCT  
TO TWO MUSHROOM HEAD  
DISTRIBUTORS

**MONO**  
DOSING OF ONE PRODUCT  
TO MUSHROOM HEAD  
DISTRIBUTOR

**TWIN**  
INDEPENDENT DOSING OF  
TWO PRODUCTS TO ONE  
MUSHROOM HEAD  
DISTRIBUTOR

CONTACT TELEPHONES:  
+34 976 166 141  
+34 638 400 081  
MAIL:  
info@lecitech.com

Central Offices:  
WTCZ Torre Oeste, Planta 15  
Avda. María Zambrano, 31  
50018 ZARAGOZA (ESPAÑA)

Factory & Warehouse:  
Calle Almendro N° 8B  
50160 Leciñena  
ZARAGOZA (ESPAÑA)



GRUPO LECITECH

[www.lecitech.com](http://www.lecitech.com)

# PRESSURISED FRONT HOPPER OR SEEDS AND FERTILISERS.

MODEL:

*Fertimax 2300*  
2300 LITRE.

## CONTROL PANEL IN CABIN

MANAGEMENT OF MACHINE ALARMS AND PARAMETERS



## DESCRIPTION:

- 1 OVEN-CURED EPOXY PAINT.
- 2 STAINLESS STEEL DISTRIBUTOR.
- 3 NECESSARY OIL FLOW = 25-30 L/MIN.
- 4 CALIBRATION EQUIPMENT.
- 5 ANTI-ERROR SYSTEM WITH DOUBLE SAFETY VIA NON-RETURN VALVE TO PREVENT PROBLEMS WHEN COUPLING.
- 6 RADAR / GPS (OPTIONAL).
- 7 CATEGORY II COUPLING.
- 8 WORKING SPOTLIGHTS.
- 9 DRIVING HEADLIGHTS.
- 10 MAXIMUM VISIBILITY FROM TRACTOR CABIN.
- 11 MANOMETER: PRESSURE CONTROL FROM OPERATOR STATION.
- 12 INTERIOR GRILL.

## OPCIONES:

TUBE FOR PASSAGE OF PRODUCT ON TRACTOR.

FLEXIBLE ANTI-ABRASION TUBE (FOR PASSAGE OF PRODUCT TO SEEDER).

MUSHROOM HEAD DISTRIBUTOR FOR PRODUCT ON CONVENTIONAL SEEDER\*.

CYCLONE FOR LOADING PRODUCT TO SEEDER.

STORAGE WHEELS.

GPS SPEED CONTROL.

AIR INTAKE SNORKEL FOR TURBINE, PREVENTING ENTRY OF LARGE LEAVES FROM CORN AND OTHER PREVIOUS CROPS.

AGITATOR FOR DIFFICULT SEEDS: ALFALFA, RAPESEED, RAY - GRASS, OATS,...



PRESSURISED **FRONT HOPPER** OR SEEDS  
AND FERTILISERS.

MODEL: *Fertimax 2300*  
2300 LITRE.



## SPECIFICATIONS:

### STAINLESS STEEL DISTRIBUTOR

MAXIMUM DURABILITY EVEN  
WITH FERTILISERS



### PRECISION

POSSIBILITY OF THREE  
TAILOR-MADE ROLLERS (\*):  
A - FROM 2 TO 20 KG/HA  
B - FROM 5 TO 200 KG/HA  
C - FROM 100 TO 400 KG/HA  
STANDARD: TYPE C



### CALIBRATION EQUIPMENT



### RADAR / GPS (OPTIONAL).

SPEED MEASUREMENT SYSTEM  
BY RADAR WHICH ALLOWS  
MAXIMUM PRECISION WITHOUT  
THE NEED FOR WHEELS  
OR CONNECTION TO OTHER MACHINES.  
OPTION: IN PLACE OF RADAR,  
GPS EQUIPMENT.





### HEAD CONTROL AND MANAGEMENT SYSTEM

HYDRAULIC OR ELECTRIC DEPENDING ON TRACTOR USED AND DRIVER PREFERENCES. ELECTRICAL PRECHARGE SYSTEM FOR SYSTEM FOR STARTING FROM OFF.

### SNORKEL OPTIONAL

PREVENTS ANY BLOCKAGE OF AIR INLET BY OVERSIZED RESIDUE FROM PREVIOUS CROPS.



### WORKING SPOTLIGHTS AND DRIVING HEADLIGHTS

GUARANTEE VISIBILITY ON THE ROAD AND FOR WORKING AT NIGHT.

### RELIABILITY

ELECTRONIC CALIBRATION SYSTEM.



### MAXIMUM VISIBILITY

MAXIMUM VISIBILITY FROM THE TRACTOR CABIN TO ENSURE OPTIMUM WORKING CONDITIONS AND SAFETY WHEN ON THE ROADS.



### PROCESS CONTROL

FROM THE OPERATOR STATION YOU CAN CONTROL: HOPPER PRESSURE, TURBINE SPEED AND HOPPER PRODUCT LEVEL. AN ALARM SOUNDS IN THE EVENT OF SERIOUS ERROR.

## FERTIMAX FRONT HOPPER VERSION: TWIN

INDEPENDENT DOSING OF TWO PRODUCTS TO SINGLE MUSHROOM HEAD DISTRIBUTOR

